

Microtechnology –New Paradigm For Process industries

Goran Jovanovic

Oregon State University

School of Chemical, Biological, and Environmental Engineering

In Affiliation With

MBI

Microproducts Breakthrough Institute

ONAMI

Oregon Nanoscience And Microtechnologies Institute

Microtechnology

The study, development, and application of devices whose operation is based on the scale of **1-100 microns**.

(A human hair is approximately
100 microns thick.)

Image source: <http://www.flickr.com/photos/thestarshine/69591402/>




Nature's Microtechnology


Nature has selected the micro scale for the realization of many biological processes.



Leaf



Alveoli



Kidney

What is Microtechnology Good For?

- Production of information
 - lab-on-chip
- Production of services
 - pacemaker
 - kidney dialyser
- Production of energy and bulk material
 - chemicals
 - fuels
 - nanoparticles

Micro/Nano Technologies Under Development In Dr. Jovanovic Laboratory

- **Microreactors for Biodiesel Production.**
- **Microreactors for Production H_2O_2 .**
- **Microreactor for Desulphurization of Fuels.**
- **Microseparators for Liquid-Liquid Extraction.**
- **Microreactors for Production of Veins and Arteries.**
- **Micro Haemo Dialyser.**
- **Microreactor for Destruction of Toxic Waste.**
- **Microseparators for Desalination of Water**
- **Microreactors for Steam Reforming (atm, 1100°C)**

Fundamental Advantages of Microtechnology

- **Intensification of Heat and Mass Transport**
 - Small scale - Short time of mass and heat transport ($\tau = l^2/D$)
- **Reduced Size**
 - 10-100 times reduction in hardware volume over conventional technology;
 - 5-50 times reduction in hardware mass;
 - Shifts size-energy trade-offs toward higher efficiency;
 - Able to integrate heat exchanges with reactors and separators simplifying processes.
- **Large surface to volume ratio (10^5 - 10^8 m²/m³)**
- **Changes chemical product distribution**

Fundamental Advantages of Microtechnology

- **Low Pressure Drop**

Reduces power for pumps, fans, and blowers;

- **Gravity independence**

Gravity effect diminish to surface and hydrodynamics forces as size of channels decreases;

- **High Degree of Reaction Control**

Minimizing unwanted environmental and side reactions;

Minimize unwanted reversible reactions;

Enables processing of very energetic reactants;

Intensification of chemical kinetics (*the last frontier in mass transport*)

- **Extremely High Quench Rates**

Small reactant volumes mean less mass or energy required to quench;

Extremely rapid heat transport enables fast thermal discharge.

Advantages of Microtechnology-Parallel Architecture

- **Fast screening of materials, catalyst and processes**
- **Flexibility in capacity and in design**
 - Provides for deployment at wide range of scales;
 - Facilitates gradual expansion of capacity as scale of operations grows by adding more modules;
- **Operating robustness and controllability**
 - Enhances reliability, allowing problems to be isolated and repaired.
- **Mass Production of Microscale Components**
 - Microlamination process enables mass production;
 - Bonded stacks can contain multiple processes;
 - Multiple processes in a single device reduces field assembly and testing.


Commercial Advantages of Microtechnology

- Lower capital investment;
- Lower operating cost;
- Faster transfer of research to commercial production;
- Earlier start of production at lower cost
 - Reduces life-cycle costs through early testing at implementation scale;
- Easier scale up (numbering -up) to production capacity;
- **Distributed technology implementation** (distributed production);
- **Integration of micro-technologies with other systems;**
- Lower cost of transportation of material and energy;
- Replacing batch with continuous processes.


Safety and Security **Advantages**

- **Small channel inhibits flame/explosion front propagation;**
- **Small volumes translate to low stored energy;**
- **Smaller volume less hazardous materials in the process.**

Sweet Spot of Microtechnology





Micro-Scale Reactors





First MECS micro-reactor, OSU 1999


Catalyst and Catalyst Deposition





Catalyst and Catalyst Deposition





Catalyst and Catalyst Deposition












FeAl 200 μm thick sheet, operating temperature 1100 °C




GoNano Technologies Inc.
121 W Sweet Ave, Suite 115, Moscow ID 83843


b)

Mag = 5.00 K X


1 μ m
|-----|




Microreactors




Microreactors





Experimental Setup – Biodiesel Production




Scale-Up = Numbering-Up















Biodiesel Production




Various Views - Biodiesel Microreactor




Biodiesel	
Heating Fluid	
Methanol	
Crude Oil	
Glycerol	


Single Stage Biodiesel Microreactor



Two Stage Biodiesel Microreactor




Exploded View - Biodiesel Microreactor




Micromixer Plates

Mixing Channels




Alcohol Feed Channel





Sintered SS Plate

Microreactor Design


Reactor Channels
Separator Plate
Reactor Channels







The Integrated 3-Stage Biodiesel Plant



Size

20" X 16" X 8"

Capacity


12ml/min =

~4.5 gal/day


1500 gal/year

Oxidative desulfurization of fuels

Thiophene





Dibenzothiophene




Oxidative desulfurization - Reaction kinetics

The desulfurization reaction kinetics is approximated with a pseudo 1st order rate model. The pseudo 1st order approximation is associated with the overall degradation reaction of thiophene which consist of the following steps:




Desulfurization of Fuels Two-phase microreactor



- Two reactants enter micro-channel separately with flow rates Q_1 and Q_2 ;
- Two phases have different properties (D, ρ, μ, σ)


Experimental Set-up

Hexane phase
(300 ppm Thiophene/Dibenzothiophene)




Experimental Setup for Interface Reactions

Desulphurization of Fuels




Experimental results

Desulphurization of Fuels




Experimental Results and Model Simulation

Thiophene concentration at spacer thickness = 50 μm




Published data by other researchers



- Batch reactor - T - 70oC [20]
- ▲ Batch reactor - DBT - 30% H2O2 - 50oC - λ =280nm [36]
- ◆ Batch reactor - 4,6-DMDBT - no H2O2 - air=1L/min - 50oC [22]
- Batch reactor - DBT - no H2O2 - air=0.5L/min - 50oC [23]
- Batch reactor - DBT - no H2O2 - air=1L/min - 50oC [22]
- ▲ Batch reactor - DBT - 30% H2O2 - 50oC [23]


Comparison with other researchers




OSU Data

- | | |
|---|---|
| ■ Batch reactor - T - 70oC [20] | ■ Batch reactor - DBT - no H ₂ O ₂ - air=0.5L/min - 50oC [23] |
| △ Batch reactor - DBT - 30% H ₂ O ₂ - 50oC - λ>280nm [36] | ○ Batch reactor - DBT - no H ₂ O ₂ - air=1L/min - 50oC [22] |
| ◇ Batch reactor - 4,6-DMDBT - no H ₂ O ₂ - air=1L/min - 50oC [22] | ▲ Batch reactor - DBT - 30% H ₂ O ₂ - 50oC [23] |
| ◆ Microreactor - T - 100 mm | ● Microreactor - T - 50 mm |
| ◇ Microreactor - T - 50 mm | |

DBT Conversion at 50 μm Homogenous Microreactor




DBT Conversion in 50 μm Microreactor



Microtechnology Based Processes


Steam Reforming of CH₄ and Biodiesel

Two 25.0 mm × 7.5mm × 220 μm microchannels separated by
200 μm catalyst support plate with a catalytic surface of 165 mm²
T=1000°C





Microtechnology Based Processes

Steam Reforming of Hydrocarbons





Microtechnology Based Processes

Steam Reforming of Hydrocarbons




Curtsey of Dr. Al-Khaldi


Microtechnology Based Hemodialyzer



Microtechnology Based Hemodialyzer



Microtechnology Based Desalination Capacitive Deionization Cell (CDT)



We expect the following advantages of Capacitive Desalination over best commercially available technology (RO Desalination)

- The concept can approach the theoretical limit on minimum energy consumption; initially, we are projecting energy consumption of 1.5 – 4.0 [kWh/m³] fresh water produced;
- Flexible capacity – from small to very large units (numbering-up v.s. scale-up)
- Possibility of use of renewable energy at the point of use (solar/wind)
- Lower capital investment;
- Lower operating cost;




Typical Development Steps

- Build and demonstrate a nominal size technology unit.
- Develop inexpensive large scale manufacturing technology for microscale devices.
- Educate new generation of PhDs capable of introducing Microtechnologies worldwide.
- Launch new small business ventures and create jobs.

Jovanovic's Microtechnology Team

Students are Our Greatest Asset



Ensuring a sustainable future requires well-educated students who are not afraid of new technological world.

- Kasidid Asumpingpong, M.Sc.
- James Parker, Ph.D
- Joy Das, M.Sc.
- Daniel Haller, Ph.D.
- Eric Anderson, Ph.D.
- Brian Reed, Ph.D.
- Eileen Hebert, M.Sc.



People. Ideas. Innovation.

Thank you for your attention!